



PERMA-CAL INDUSTRIES, INC.
1742 Orbit Way
Minden, NV 89423-4114
(775) 782-1026 FAX (775) 782-1056
www.perma-cal.com

REGULATOR PANEL MOUNTING INSTRUCTIONS

INSTALLATION DETAILS:

1. READ ALL INSTRUCTIONS THOROUGHLY BEFORE PROCEEDING.
2. REMOVE THE 2 SCREWS FROM THE RANGE PLATE AND REMOVE PLATE
3. WHILE HOLDING THE KNOB SECURELY IN ONE HAND, REMOVE THE JAM NUT (5/8" HEX).
4. PLACE A SCREWDRIVER BLADE IN THE SLOT OF THE THREADED SHAFT AND REMOVE THE KNOB BY ROTATING CCW.
5. INSTALL ONE PANEL NUT ON THE REGULATOR (1 1/2" HEX).
6. DRILL-FLY CUT \varnothing 1.34/1.37 HOLE IN THE PANEL.
7. INSERT THE REGULATOR IN THE PANEL HOLE FROM BEHIND THE PANEL, ROTATE THE REGULATOR INTO THE DESIRED POSITION, INSTALL AND TIGHTEN THE SECOND PANEL NUT.
8. INSTALL THE KNOB USING THE SCREWDRIVER TO PREVENT ROTATION OF THE THREADED SHAFT. TURN THE KNOB CW (WHILE HOLDING THE SHAFT) UNTIL APPROX. .38" OF THE SHAFT PROTRUDES ABOVE THE TOP RECESS OF THE KNOB.
9. INSTALL THE JAM NUT USING A SMALL AMOUNT OF LOCTITE NO. 222 (BLUE). TORQUE TO 100 IN-LBS.
10. REPLACE RANGE INFORMATION PLATE.

